



IMPORTANT DOCUMENTATION, PLEASE READ BEFORE USING YOUR TRAYS!

Care and Maintenance of Your Trays:

- Avoid extreme temperature variations such as resting directly against a window pane
- When dirty or dusty, wipe with a damp lint free cloth, soap is not required.
- Let Trays dry for up to 24 hours at 65 degrees and ensure they are dry before placing inserts and/or items.
- Do not overload Trays with too many objects, this may strain the compartments. If the Tray starts sagging due to overly heavy figures, be sure to remove items until it returns to its normal shape.
- If the Tray gets deformed remove all items and wait up to 24 hours for it to return to its normal shape. The more severe the deformation the longer it may take to return to its original shape.
- If using inserts, it is suggested to remove them prior to using Trays for long term storage.

General Tips for Tray Display & Storage Options:

- Ideally, it is recommended to display figures on action figure stands for the best combination of balance and safety.
- Use a regular book shelf or an IKEA Detolf® to really show off your Trays and Action Figures
- It is not recommended to stack Trays vertically in Display Mode without some additional support
- Avoid direct sunlight and florescent lights - these sources may cause color fading to your Figures
- In Storage mode, you can safely stack 4-6 Trays fully loaded on a shelf. A Banker's/Office Box (15x12x10) will hold 4 Trays perfectly

General Tips for Overall Tray Usage:

- Please use a common sense approach to handling the Trays with your valuable figures
- If in a vertical Display Mode you are holding and moving a fully loaded Tray, always hold the Tray at an angle with your thumb resting on a support wall, ensuring a good grip, to make sure figures do not fall out. In all other cases, a fully loaded Tray should be held with two hands supporting each side, similar to a pizza box
- Make sure the surface you are mounting the Trays on is prepped properly and is flat
- It is suggested to mount the Tray at 4 points for maximum stability
- Before inserting figures into the Trays make sure the installation method used to mount the Trays is secure, use action figure stands when possible or lean figures against the back compartment wall to prevent figures falling forward
- Do NOT have more than one item per compartment if the Tray is mounted to the wall
- Do NOT try to mount the Trays with items already inside, mount first, then place items inside
- When removing Trays from the wall surface, please remove all items first
- If using an adhesive based mounting option (such as an industrial strength velcro) make sure the adhesive portion of the mount has fully cured and bonded with the Tray back, it should be semi permanent in its fixture (Please note that only industrial types of adhesives will produce a suitable bond to the Tray's XLPE material)

BY USING OUR TRAYS YOU ACCEPT THE FOLLOWING DISCLAIMER:

In no event shall Toy-Gear Inc. be liable for any direct, indirect, punitive, incidental, or special consequential damages to property or life, whatsoever arising out of or connected with the use or misuse of our products.

www.TOY-GEAR.com

ACTION FIGURE COLLECTOR TRAYS

Guide for Inserts and Mounting:



Cut along the dotted lines to create a snug fit



Maneuver the insert in and use a flat non-sharp tool so the insert stays flush against the walls. Use a similar tool to carefully pry up the insert edge



For mounting, measure and line up on each of the 4 corners of the Tray



Make sure that if you screw your Trays to the wall, use a washer and the flattest head screw possible



The inserts should successfully camouflage the screw mounts. Always position the Tray on the wall without figures



Once the Tray is secure and straight, place figures on figure stands (not included) and enjoy. Prior to removing the Tray, be sure to remove all figures first